

How to Construct a Short Board

1. Use Bandsaw to cut the width of your board.
2. You and a helper your cut your skate deck.
3. Clamp your deck to the table.
4. Cut ends with jigsaw. Cut as close as you can to the pattern line (**Don't Cut The Table**)
5. Go to disc sander and sand down to the pattern line.
6. Use rasp to round over all the edges. Top and Bottom.
7. Use portable hand sander to sand the edges.
8. Get pattern for trucks and tape it to your board in the correct position.
9. Center punch in the middle of each circle
10. Throw away pattern and drill the holes at the drill press (Delta)
11. Picture Frame must be handed to Kuhn before going on to the next step.
12. Put on Grip Tape
13. Punch out drill holes and use box cutter to make designs in grip tape.
14. After you board has been taken home I will pass out the trucks and wheels.