

NAME _____

WOODEN BANK PLANS

1. Layout Coin Slot on Masonite (Figure 1 on back of this paper)
2. Layout nail holes on 3/4" thick pine. (Figure 2 on back of this paper)
3. **DRILL PRESS (DELTA)** - Drill 4 hole in piece of pine.
4. **BAND SAW** - Cut out the Coin Slot on the piece of masonite.
5. Hand in scrap pieces from Coin Slot to get other piece of Pine.
6. Glue and nail Masonite sandwiched between 2 pieces of Pine.
Show Kuhn all 3 pieces to get baggy of nails to baggy of nails
7. Put in vice with dry paper towel & sand sides with used sand paper
Leave in Vice. Wood elves will take you project out for you.
8. Draw an 'X' on bottom (side opposite of Coin Slot)
9. **DRILL PRESS** - Drill 1" hole on the bottom.
10. Layout legs (Figure 3 on back of this paper) and Get Graded
11. **DRILL PRESS** - drill two 3/4" holes at **Drill Press #1**
12. Draw lines to match Figure 4, on back of this paper, & Show Kuhn.
13. **BAND SAW** - cut out legs
14. Use file to smooth out cut made at Bandsaw - Get Graded
15. Stamp First and Last name on the bottom.
16. Layout inside of Bank - (Figure 5 on back of this paper) Show Kuhn
17. **DRILL PRESS** - Drill four 3/4" holes at **Drill Press #2**
18. Draw lines to match Figure 6 on back of this paper and show Kuhn.
19. **Portable Jig Saw** - put project in vice and cut out inside of Bank
20. Use Files to smooth out cuts made by Jig Saw. Get Graded.
21. Sand Handle with 60 grit then with 200 grit, then with 600 grit.
22. Show Kuhn to get front and back part of Bank.
23. Layout nail holes on each piece (Figure 2 on back of this paper)
change 1/2" to 1/4" when laying out holes.
24. Bring up front & back pieces and plans (this paper) to get nails.
25. Start 8 nails in front and back pieces.
26. Apply glue and nail front and back in place.
27. Put in vice with dry paper towel & sand sides with used sand paper
Leave in Vice. Wood elves will take your project out for you.
29. Sand all sides even and round over all edges except the bottom.
30. Hand in 60 grit to get 200 grit. Sand entire project.
31. Hand in 220 grit to get 600 grit. Sand entire project.
32. Hand in 600 grit. Stain project.
33. Put in period 6 cabinet to dry.
34. Do evaluation. **EVALUATION MUST BE IN PENCIL**
35. Hand in evaluation, project (get from period 6 cabinet), & Plans